


SPARE PARTS LIST

ITEM	QTY	PART NO.	DESCRIPTION
1	3	A00459	HHCS, 5/8-11 x 8.00, GR 8, ZINC PLATED
2	6	A00461	LOCK WASHER 3/8"
3	6	A00464	LOCK WASHER 3/4"
4	3	A00467	HUT, HEAVY HEX, 5/8-11, GR 8, ZINC PLATED
5	6	A00468	NUT, 3/4-10, GR 8, ZINC PLATED
6	1	A00474	GREASE ZERK 1/4-18 NPT
* 7	2	A00486	BEARING CUP
* 8	2	A00487	BEARING CONE
* 9	1	A00488	RETAINING NUT
* 10	1	A00489	BEARING LOCK WASHER
11	4	A00490	COTTER PIN
12	2	A03021	SENSOR PIN
13	4	A03022	BUSHING
14	6	A07845	HHCS, 3/8-16 x 1.00, GR 8, ZINC PLATED
15	6	A07846	HHCS, 3/4-10 x 4.00, GR 8, ZINC PLATED
16	3	A12991	LOCKWASHER, 5/8
17	3	A19037-00561-0	3/4" SCH 40 PIPE GALVANIZED x 5.61, NO THREADS
** 18	1	A19321	LINE CLAMP INSERT
19	1	B99516	LINE CLAMP CAP ASSEMBLY

* ITEMS NOT SHOWN. SEE BEARING MANUFACTURER FOR MAINTENANCE PRACTICES



** LINE CLAMP INSERTS

HERCULES PART NO.	DESCRIPTION
HA118-024100	INSERT, SET, 1" WIRE ROPE
HA118-024112	INSERT, SET, 1-1/8" WIRE ROPE
HA118-024125	INSERT, SET, 1-1/4" WIRE ROPE